

Honeywell Eltek FireWin Delta

PACOM Unison effectively links Honeywell Eltek FireWin Delta products with other sub systems such as access control, alarm and video to provide a powerful, automated fire control and building management solution.

FEATURES

REAL-TIME MONITORING

| | |
|-------------------------------------|---|
| Communication errors | ✓ |
| Hardware errors | ✓ |
| System faults | ✓ |
| Sensor values | x |
| System status (e.g. power, battery) | ✓ |

ALARMS

| | |
|---|---|
| Receive fire alarms | ✓ |
| Receive trouble alarms (e.g. loss of communication) | ✓ |
| Receive supervisory alarms | ✓ |
| Receive AC fail | ✓ |
| Receive battery low/battery failure | ✓ |

ALARM HANDLING

| | |
|---------------------|---|
| Acknowledge alarms | ✓ |
| Silence alarms | ✓ |
| Reset/Cancel alarms | ✓ |

AUDIT TRACKING

| | |
|------------------------------|---|
| Alarm responses logged | ✓ |
| Configuration changes logged | ✓ |

ENABLE/DISABLE EXTERNAL UNITS

| | |
|-------------------------------------|---|
| Enable/Disable detectors | ✓ |
| Enable/Disable sounders | ✓ |
| Enable/Disable ventilation outputs | x |
| Enable/Disable sprinkler outputs | x |
| Enable/Disable extinguisher outputs | x |

OTHER

| | |
|---|---|
| Isolate inputs | ✓ |
| Activate outputs | x |
| Activate/Disable test mode | x |
| Sound audible alerts on the Operator's monitor when an alarm goes off | ✓ |
| Trigger action on cameras, doors, etc. | ✓ |
| Automatically upload panel/system data | ✓ |
| Display alarms on graphical maps | ✓ |
| Import fire panel configuration | ✓ |

COMPATIBILITY

| | |
|-------------------------------|---|
| Unison Version | 5.7 or later |
| Honeywell Eltek FireWin Delta | Eltek FireWin OPC server version 2.10 Protocol: OPC DA v2.0 |